

ULM FK




- (DE) Montageanleitung
(PL) Instrukcja montażu
(NL) Handleiding voor de montage
(GB) Assembly instructions
(TR) Montaj talimatı
(RU) Инструкция по монтажу

- (IT) Istruzioni di montaggio
(FR) Notice de montage
(RO) Instrucțiuni de asamblare
(SK) Montážny návod
(CZ) Montážní návod
(HU) Szerelési útmutató




Service - Servis - Dienstverlening - Servis - Serwis - Сервисная служба - Servizio - Service
Serviciu - Služby - Szolgáltatás

Name - Nazwa - Naam - Name - Isim - название
Nome - Nom - Numele - Meno - Jméno - Neve


ULM FK




9 x (4x16) a	4 x (5x50) b	4 x 50mm 50mm V	2 x 50mm 50mm Z	2 x W	6 x (M6x35) c	6 x f
2 x 48cm 70cm 1	2 x 25cm 70cm 2					



1



2



3

